

Anschluss-Berater · Connection Guide

Anschluss-Tabelle · Connection Chart

Welche Geräte verbinde ich mit welchen Kabeln?

Anhand der hier angegebenen Anschluss-Nummer(n) ● ○ können Sie in der Tabelle rechts das passende Kabel finden.

The suitable cable connection between two components is shown by the connection No ● ○. The right table gives more information about the cable by the recommended connections No.

| ▼ Output ▼ | ▼ Input ▼ | | | | | | | | | | | | |
|---------------------------|----------------------|-----------------------------|----------------------------------|-------------------------|------------------|---------------------------------------|--|--------------|-------------|--------------------|---------------------------------------|-----------|------------------|
| | Verstärker/Amplifier | AV Receiver | Blu-ray Recorder | CD Recorder / Mini Disc | DVD Recorder | [Media] PC / Laptop | Projector / Beamer | SAT Receiver | Set Top Box | Subwoofer (active) | TV / LCD / Plasma | Tape Deck | Video Recorder |
| Verstärker/Amplifier | | | 1 | 1 | 1 | 2 | 1 | | | | 1 | 1 | 1 |
| AV Receiver | | | 5 7 11 | 1 6 8 | 5 6 | 4 5 6 7 8 11 | 3 4 5 6 7 8 11 | | | 1 3 | 3 4 5 6 7 8 11 | 1 | 5 |
| Blu-ray | 1 | | 1 3 5 6 7 8 11 | 1 | 1 3 5 6 | 2 3 4 5 6 7 8 11 | 1 2 3 4 5 6 7 8 11 | | | | 1 3 4 5 6 7 8 11 | 1 | 1 3 5 6 |
| CD | 1 3 8 | | | 1 3 8 | | 1 3 8 | | | | | | 1 | 1 |
| DVD | 1 3 8 | 1 3 8 | 5 | 1 6 | 1 5 6 | 1 3 4 5 6 7 8 11 | 3 4 5 6 7 8 11 | | | | 1 3 4 5 6 7 8 11 | 1 | 5 6 |
| Game Console | 1 3 8 | 1 3 8 11 | | | | | 5 7 11 | | | | 7 8 11 | | |
| MP3 Player, Portable CD | 2 | 2 | | 2 | | 2 | | | | | | 2 | 2 |
| [Media]-PC / Laptop | 1 2 3 8 | 1 2 3 5 7 11 | 5 | 1 | 5 | 3 5 6 7 8 11 | 3 5 6 7 8 11 | | | | 1 3 5 6 7 8 11 | 1 | 5 6 |
| SAT Receiver, Set Top Box | 1 3 8 | 1 3 5 7 8 11 | 5 | 1 8 | 5 6 10 | 5 6 7 8 11 | 3 5 6 7 8 11 | 6 | 6 | | 5 6 7 8 11 | 1 | 5 6 |
| SAT TV | | | 9 | | 9 | | | 9 | | | 9 | | 9 |
| Cable TV | | | 10 | | 10 | 10 | | 10 | | | 10 | | 10 |
| Tape Deck | 1 | 1 | | 1 | | 1 2 | | | | | | 1 | 1 |
| Video Camcorder | 4 7 11 | 4 7 11 | 2 | | | 4 7 11 | 4 7 11 | | | | 4 7 11 | | 4 |
| Video Recorder | 1 | 1 | 5 6 | 1 | 5 6 | 5 | 3 5 | | | | 5 6 | 1 | 5 6 |

● = Standardanwendung normal use
○ = in Sonderfällen possible in different cases

HICON
HI-FI & HOME

www.hicon-hifi.com

HICON – A Division of SOMMER CABLE

| Anschluss-Nr. Connection No. | AMBIENCE SERIES | | Audio = ● Video = ○ | Länge/ Length |
|---------------------------------|---|---------------------------------------|------------------------|---|
| | links · left | rechts · right | | |
| 1 | Stereo Audio 2x Cinch | Stereo Audio 2x Cinch | ● ○ | 0.75 m 1.5 m 3 m 5 m |
| 2 | Stereo Audio 1x 3.5 mm Mini-Klinke/ Jack | Stereo Audio 2x Cinch | ● ○ | 1.5 m 3 m 5 m |
| 3 | SPDIF 75 Ω 1x Cinch | SPDIF 75 Ω 1x Cinch | ● ○ | 1.5 m 3 m 5 m 10 m |
| 4 | Mini-Klinke/ Jack 3.5 mm 4 pol | Composite AV 3x Cinch | ● ○ | 1.5 m 3 m 5 m |
| 5 | Component YUV 3x Cinch | Component YUV 3x Cinch | ● ○ | 0.75 m 1.5 m 3 m 5 m |
| | Auch als Composite-Kabel einsetzbar Usage as composite A/V cable is possible | | | |
| 6 | SCART flat cable | SCART flat cable | ● ○ | 0.75 m 1.5 m 3 m 5 m |
| | SCART round cable, connector 45° | SCART round cable, connector straight | | |
| 7 | HDMI 1.3b flat cable | HDMI 1.3b flat cable | ● ○ | 0.75 m 1.5 m 3 m 5 m 10 m 15 m |
| 8 | Optical TOSLINK | Optical TOSLINK | ● ○ | 0.75 m 1.5 m 3 m 5 m |
| 9 | SAT F-Plug | SAT F-Plug | ● ○ | 0.75 m 1.5 m 3 m 5 m 10 m |
| 10 | Antenna male | Antenna female | ● ○ | 0.75 m 1.5 m 3 m 5 m 10 m |
| 11 | Display Port male | Display Port male | ● ○ | 0.75 m 1.5 m 3 m 5 m 10 m 15 m 20 m |